

Elevators

Make 6

3mm Depron

Front Motor Mount Bulkhead #3

Make 4

Behind Motor Mount Bulkhead #5

Make 4

#7

Make 4

Main Wing

Make 4

3mm Depron

Carbon Spar Tube Slot

Underside Bulkhead #2

Underside Bulkhead #3

Carbon Spar Tube Slot

Underside Bulkhead #4

Underside Bulkhead #5

Underside Forward Fuselage Section

Make 4

Underside Rear Fuselage Section

Make 4

Forward Underside Missle Bays

Make 2

3mm Depron

Tail Section Center Boom

Make 3

EDF Mount Suports

Make 4

Tail Hook *Make 2* *3mm Depron*

Wing Gluing Support Braces *Make 8* *3mm Depron*