



1/2" balsa fin ribs
shaped to match fin
cross section.

Shape the fin/rudder cross
section then sheet fin with 1/32"
or 1/6" light balsa from leading
edge through 1/8" past the
rudder post so that the rudder
hinge is inset from the sheeting
line.

3/16" x 1/2"
hard balsa

1/8" hardwood
tail skid.

Carry fin posts through into fuselage

